

Filo muro/ swing doors

FINISHING INSTRUCTIONS



DAYORIS
DOORS

Suggested finishing instructions, finish by others

Filo muro/ Swing doors, Finishing instructions

1. Apply mesh tape covering the transition area between the wall stud and Dayoris door frame.



Suggested finishing instructions, finish by others

Filo muro/ Swing doors, Finishing instructions

2. Apply 2 to 3 thin plaster coats over mesh tape covering entire flush side of Dayoris Frame. Plaster finishing should float from edge of aluminum frame to wall in order to create a flush finish appearance.



Suggested finishing instructions, finish by others

Filo muro/ Swing doors, Finishing instructions

3. Rear (non flush) side finishing technique. Insert sheetrock piece on jamb side into open cavity on aluminum frame. This piece should be shimmed in order to create a level 90° angle at the beginning of the wall on the non-flush side. The non-flush side of the wall, and inserted sheetrock jamb piece, needs to be joined with corner bead. This will create a clean edge with a 90° angle.

